








DSC Quick Reference

-  **ARM SYSTEM:** Hold [Away Arm] button for 2 sec, or [CODE]
-  **ARM PERIMETER ONLY:** Hold [Stay Arm] button for 2 sec, or [CODE] and do NOT open any entry/exit doors
-  **DOOR CHIME TOGGLE:** Hold [Chime On/Off] button for 2 sec, or [*] + [4]
-  **CANCEL ALARM:** [CODE] + [#]
-  **PANIC:** Hold [POLICE] or [FIRE] for 5 sec.



ENTER NEW USER CODE(S):

[*] + [5] + [MasterCode]. Scroll to or enter desired user #, then press [*] + [NewCode] + [#]
Users can arm and disarm system but cannot change their codes, please keep track of your users from 01 to 38, 41-95 on the provided chart. Optional attributes can be applied below...

SET USER ATTRIBUTES:

[*] + [5] + [MasterCode] + [99] + [UserNumber] + [AssignAttribute#] + [#]

Attribute #'s:

[1] = User can enter User Code Programming section with this code

[2] = Duress Reporting Code is sent whenever this code is entered

[3] = User can manually bypass zones

[7] = The panel will squawk the bell output when the user arms/disarms

[8] = One-time use code per day – Can disarm the system once per day and is reset at midnight

DELETE USER CODE:

[*] + [5] + [MasterCode]. Scroll to or enter desired user #, then press [*] + [*] + [#]

Permanently removes user code and attributes from the system.



INFORCE SECURITY CORP.

DIGITAL VIDEO RECORDING AND SURVEILLANCE
BURGLAR, SMOKE AND INTRUSION DETECTION

Please keep track of your existing users and codes on this chart and store in a safe place.

User	Nickname	Code	Attributes
01			
02			
03			
04			
05			
06			
07			
08			
09			
10			
11			
12			
13			
14			
15			
16			
17			
18			
19			
20			
21			
22			
23			
24			
25			
26			
27			
39			
40	MASTER		